






Kuchnia nastawna MODEL: 970513







Palnik 3,5kW



Palnik 7kW

LP.	Numer katalogowy	Nazwa części
1	V970513-01	Ruszt
2	V970513-02	Blat z kominkiem
3	V970513-03	Misa
4	V970513-04	Termopara
5	V970513-05	Rura pilota (ø6x1)
6	V970513-06	Rura zasilająca (ø10x1)
7	V970513-07	Termopara
8	V970513-08	Zawór
9	V970513-09	Klamra zaworu
10	V970513-10	Pokrętło ze skalą
11	V970513-11	Zaślepka rury
12	V970513-12	Rura 1/2"
13	V970513-13	Łącznik
14	V970513-14	Wspornik palnika
15	V970513-15	Obudowa
16	V970513-16	Nóżka
17	V970513-17	Korona 3,5kW
18	V970513-18	Kielich 3,5kW
19	V970513-19	Wspornik pilota
20	V970513-20	Wspornik palnika
21	V970513-21	Przesłona
22	V970513-22	Dysza palnika
23	V970513-23	Wspornik dyszy
24	V970513-24	Kolano
25	V970513-25	Korona 5kW
26	V970513-26	Kielich 5kW
27	V970513-27	Wspornik pilota
28	V970513-28	Wspornik palnika
29	V970513-29	Przesłona
30	V970513-30	Dysza palnika
31	V970513-31	Wspornik dyszy
32	V970513-32	Kolano
33	V970513-33	Palnik 3.5kW
34	V970513-34	Palnik 5kW