






Kuchnia nastawna MODEL: 970511







Palnik 3,5kW



Palnik 7kW

LP.	Numer katalogowy	Nazwa części
1	V970511-01	Ruszt
2	V970511-02	Błat z kominkiem
3	V970511-03	Misa
4	V970511-04	Termopara
5	V970511-05	Rura pilota (∅6x1)
6	V970511-06	Rura zasilająca (∅10x1)
7	V970511-07	Termopara
8	V970511-08	Zawór
9	V970511-09	Klamra zaworu
10	V970511-10	Pokrętło ze skalą
11	V970511-11	Zaślepka rury
12	V970511-12	Rura 1/2"
13	V970511-13	Łącznik
14	V970511-14	Wspornik palnika
15	V970511-15	Obudowa
16	V970511-16	Nóżka
17	V970511-17	Korona 3,5kW
18	V970511-18	Kielich 3,5kW
19	V970511-19	Wspornik pilota
20	V970511-20	Wspornik palnika
21	V970511-21	Przesłona
22	V970511-22	Dysza palnika
23	V970511-23	Wspornik dyszy
24	V970511-24	Kolano
25	V970511-25	Korona 5kW
26	V970511-26	Kielich 5kW
27	V970511-27	Wspornik pilota
28	V970511-28	Wspornik palnika
29	V970511-29	Przesłona
30	V970511-30	Dysza palnika
31	V970511-31	Wspornik dyszy
32	V970511-32	Kolano
33	V970511-33	Palnik 3,5kW
34	V970511-34	Palnik 5kW
35	V970511-35	Pilot palnika