






Kuchnia nastawna MODEL: 970521







Palnik 7kW



Palnik 3,5kW

LP.	Numer katalogowy	Nazwa części
1	V970521-01	Ruszt
2	V970521-02	Błat z kominkiem
3	V970521-03	Misa
4	V970521-04	Termopara
5	V970521-05	Rura pilota (∅6x1)
6	V970521-06	Rura zasilająca (∅10x1)
7	V970521-07	Termopara
8	V970521-08	Zawór
9	V970521-09	Klamra zaworu
10	V970521-10	Pokrętło ze skalą
11	V970521-11	Zaślepka rury
12	V970521-12	Rura 1/2"
13	V970521-13	Łącznik
14	V970521-14	Wspornik palnika
15	V970521-15	Obudowa
16	V970521-16	Nóżka
17	V970521-17	Korona 3,5 kW
18	V970521-18	Kielich 3,5 kW
19	V970521-19	Wspornik pilota
20	V970521-20	Wspornik palnika
21	V970521-21	Przesłona
22	V970521-22	Dysza palnika
23	V970521-23	Wspornik dyszy
24	V970521-24	Kolano
25	V970521-25	Korona 7 kW
26	V970521-26	Kielich 7 kW
27	V970521-27	Wspornik pilota
28	V970521-28	Wspornik palnika
29	V970521-29	Przesłona
30	V970521-30	Dysza palnika
31	V970521-31	Wspornik dyszy
32	V970521-32	Kolano
33	V970521-33	Palnik 3,5 kW
34	V970521-34	Palnik 7 kW
35	V-70521-35	Pilot palnika