




Grill gazowy

**MODEL: 973011, 973013,
973021, 973023**





LP.	Numer katalogowy	Numer katalogowy	Numer katalogowy	Numer katalogowy	Nazwa części
1	V973011-01	V973013-01	V973021-01	V973023-01	Ostona kominka
2	V973011-02	V973013-02	V973021-02	V973023-02	Podstawa kominka
3	V973011-03	V973013-03	V973021-03	V973023-03	Komin wewnętrzny
4	V973011-04	V973013-04	-	-	Płyta grillowa płaska
	-	-	V973021-04	V973023-04	Płyta grillowa ryflowana
5	V973011-05	V973013-05	V973021-05	V973023-05	Ostona
6	V973011-06	V973013-06	V973021-06	V973023-06	Wspornik palnika
7	V973011-07	V973013-07	V973021-07	V973023-07	Wspornik
8	V973011-08	V973013-08	V973021-08	V973023-08	Podstawa pilota
9	V973011-09	V973013-09	V973021-09	V973023-09	Misa palnika
10	V973011-10	V973013-10	V973021-10	V973023-10	Izolacja 25mm 490x120
11	V973011-11	V973013-11	V973021-11	V973023-11	Korpus
12	V973011-12	V973013-12	V973021-12	V973023-12	Skrzynka przyłączeniowa
13	V973011-13	V973013-13	V973021-13	V973023-13	Instalacja elektryczna
14	V973011-14	V973013-14	V973021-14	V973023-14	Kostka ceramiczna
15	V973011-15	V973013-15	V973021-15	V973023-15	Ostona dolna
16	V973011-16	V973013-16	V973021-16	V973023-16	Puszka generatora
17	V973011-17	V973013-17	V973021-17	V973023-17	Przelotka fi6
18	V973011-18	V973013-18	V973021-18	V973023-18	Generator
19	V973011-19	V973013-19	V973021-19	V973023-19	Panel przedni
20	V973011-20	V973013-20	V973021-20	V973023-20	Termostat bezpieczeństwa
21	V973011-21	V973013-21	V973021-21	V973023-21	Włącznik
22	V973011-22	V973013-22	V973021-22	V973023-22	Stopka
23	V973011-23	V973013-23	V973021-23	V973023-23	Ostona pojemnika
24	V973011-24	V973013-24	V973021-24	V973023-24	Pojemnik
25	V973011-25	V973013-25	V973021-25	V973023-25	Ostona palnika
26	V973011-26	V973013-26	V973021-26	V973023-26	Rurka palnika głównego
27	V973011-27	V973013-27	V973021-27	V973023-27	Oczko
28	V973011-28	V973013-28	V973021-28	V973023-28	Kolektor
29	V973011-29	V973013-29	V973021-29	V973023-29	Klamra
30	V973011-30	V973013-30	V973021-30	V973023-30	Zawór piekarnika gazowego
31	V973011-31	V973013-31	V973021-31	V973023-31	Pokrętko ze skalą
32	V973011-32	V973013-32	V973021-32	V973023-32	Skala sterowanie
33	V973011-33	V973013-33	V973021-33	V973023-33	Odprowadzenie
34	V973011-34	V973013-34	V973021-34	V973023-34	Rurka pilota
35	V973011-35	V973013-35	V973021-35	V973023-35	Inżektor pilota 0,40mm
36	V973011-36	V973013-36	V973021-36	V973023-36	Inżektor pilota 0,20mm
37	V973011-37	V973013-37	V973021-37	V973023-37	Termopara
38	V973011-38	V973013-38	V973021-38	V973023-38	Pilot płomienia patelni
39	V973011-39	V973013-39	V973021-39	V973023-39	Elektroda
40	V973011-40	V973013-40	V973021-40	V973023-40	Palnik grilla
41	V973011-41	V973013-41	V973021-41	V973023-41	Regulator powietrza
42	V973011-42	V973013-42	V973021-42	V973023-42	Dysza na gaz G20/20mbar
43	V973011-43	V973013-43	V973021-43	V973023-43	Dysza na gaz G30/37mbar
44	V973011-44	V973013-44	V973021-44	V973023-44	Kolanko