





E7P6+FE

Pos. Item	Codice Code	Descrizione	Item Description	Designation articles	Artikelbeschreibung	Decripción artículos	N° pezzi - No. pieces						
1	22037800	Piastra tonda d.220 2600w 240v	2600w-240v round plate	Plaque ronde 2600w-240v	Rundplatte 2600w-240v	Plancha redonda 2600w-240v							6
2	22049900	Commutat. x cuc.piastre el.	Selector	Commutateur	Umschalter	Conmutador							6
3	00000000	Ricambio mancante	Test	-----	-----	-----							-
4A	31952500	Serig.rossa manop.cucina elet.	Electric knob serigraphy	Serigraphie manette electr.	Drehknopfserigraphie	Serigrafia mando electr.							1
4B	31952600	Serig.rossa manop.forno el.mul	Electric knob serigraphy	Serigraphie manette electr.	Drehknopfserigraphie	Serigrafia mando electr.							1
4C	31953500	Serig.rossa manop.frytop/forno	Knob serigraphy	Serigraphie manette	Drehknopfserigraphie	Serigrafia mando							6
5	30168800	Spia verde 230v d.10mmt150Ø	Green lamp 230v	Temoin lumineux vert 230v	Grune kontrollampe 230v	Piloto verde 230v							7
6	30168500	Spia arancio 230v d.10mmt150Ø	Orange lamp 230v	Temoin lumineux orange 230v	Orange kontrollampe 230v	Piloto naranja 230v							1
7	30184200	Morsettiera a 6 poli fv 122 b	Terminal board 6 poles	Bornier 6 poles	Klemmenleiste	Bornera 6 polos							1
8	31856800	Grc 2/1 gn - griglia forno cuc	Grc 2/1 gn-cooker oven grill	Grc 2/1 gn-grille four	Grc 2/1 gn- backofen-rost s.70	Grc 2/1 gn-parrilla horno							1
9	31802100	Cerniera sx forno cucine	left oven hinge	Charniere gauche four	Linksseitiges scharnier	Bisagra izda. horno							1
10	31320000	Resistenza superiore 990w 240v	990w 240v higher heating elem	RÉsistance superieur 990w 240v	Oberer widerstand 990w 240v	Resistencia superior 990w 240v							3
10	31320400	Resistenza inferiore 1500w 240	1500w 240v lower heating eleme	RÉsistance infÉrieure 1500w 24	Unteres widerstand 1500w 240v	Resistencia inferior 1500w 240							3
11	31857000	Portateglie 2/1 gn	Grill support 2/1 gn	Support grille 2/1 gn	Grillstutze 2/1 gn	Soporte bandejas de horno 2/1							2
12	31802000	Cerniera dx forno cucine	Right oven hinge	Charniere droite four	Rechtsseitiges scharnier	Bisagra derecha horno							1
13	31802500	Portarullino cerniera forno	Roller-bearing oven hinge	Porte-rouleau charniere four	Rollenhalter scharniere fuer b	Soporte rodillo bisagra horno							2
14	31858600	Guarn.fibra vetro fg/fe l=1315	Seal for oven 2/1gn l=1315	Joint pour four 2/1gn l=1315	Meter-turdichtung ofen 2/1gn l	Junta por horno 2/1gn l=1315							1
15B	30064900	Termostato trif.270Ø x fe 2/1	Thermostat 270Ø - fe 2/1	Thermostat 270Ø - fe 2/1	Thermostat 270Ø - fe 2/1	Termostato 270Ø - fe 2/1							1
15B	22062600	Termostato 300°C frytop-ebrs4	Thermostat 300°C	Thermostat 300°C	Thermostat 300°C	Termostato 300°C							1
15A	22050300	Interr. quadrip. fry-top/700;	Switch	Interrupteur	Schalter	Interruptor							1
16	22069700	Termostato trif.sicur.fry-top	Security thermostat	Thermostat de surete	Sicherheitthermostat	Termostato de seguridad							1
17	22049800	Commutatore per fe 2/1-cpe40/e	Selector - cpe40/e9cp40	Commutateur - cpe40/e9cp40	Umschalter - cpe40/e9cp40	Conmutador - cpe40/e9cp40							1
18	24684200	Piedino inox 1 1/2 h-125/175	Foot 1 1/2 h-125/175	Pied 1 1/2 h-125/175	Fuss 1 1/2 h-125/175	Pata 1 1/2 h-125/175							4
19	31876200	manopola pel rossa perno6x4,6	Electric red knob	Manette électrique rouge	Elektro-drehknopf	Mando elÉctrico rojo							6
20	32583800	Chiusura magnetica	Magnetic closure	Fermeture magnetique	Magnetverschluss	Cierre magnetico							1
21	00000000	Ricambio mancante	Test	-----	-----	-----							-